

| INSTALLATION & OPERATION MANUAL

MUF 1200

Inline Ultrasonic Flow Meter



MIAL[®]
INSTRUMENTS PVT.LTD.
Measuring & Beyond

www.mialinstruments.com

MUF 1200

Inline Ultrasonic Flow Meter

Preface

- Thank you for purchasing our product.
- This manual is about the various functions of the product, wiring methods, setting methods, operating methods, troubleshooting methods, etc.
- Please read this manual carefully before operation, use this product correctly to avoid unnecessary losses due to incorrect operation.
- After you finish reading, please keep it in a place where it can be easily accessed at any time for reference during operation.



NOTE!

Modification of this manual's contents will not be notified as a result of some factors, such as function upgrading. We try our best to guarantee that the manual content is accurate, if you find something wrong or incorrect, please contact us. The content of this manual is strictly prohibited from reprinting or copying.

About this manual

- Please submit this manual to the operator for reading.
- Please read the operation manual carefully before installing the instrument. On the precondition of full understanding.
- This manual only describes the functions of the product. The MIAL Instruments pvt.ltd. does not guarantee that the product will be suitable for a particular application.

Warnings and symbols used



HAZARD!

If not taken with appropriate precautions, will result in serious personal injury, product damage or major property damage.



WARNING!

Pay special attention to the important information linked to product or particular part in the operation Manual



CAUTION!

Disregarding these instructions can result in damage to the device or other ancillary products.



INFORMATION!

These instructions contain important information for the handling of the device.

Table of Contents

PREFACE	1
ABOUT THIS MANUAL	1
1. INTRODUCTION	3
1.1 PURPOSE OF THE MANUAL	3
1.2 OPERATING PRINCIPLE	4
1.3 TECHNICAL SPECIFICATIONS	5
2. DEVICE DESCRIPTION	5
2.1 SCOPE OF DELIVERY	5
2.2 NAMEPLATES	6
3. INSTALLATION	7
3.1 SITE SELECTION	7
3.1.1 BASIC RECOMMENDATIONS	7
3.1.2 FLOW DIRECTION	7
3.1.3 INSTALLATION OF REMOTE MOUNT TRANSMITTER	8
3.1.4 STRAIGHT LENGTH REQUIREMENT	8
3.2 MECHANICAL INSTALLATION	10
3.2.1 STANDARD TRANSMITTER DIMENSIONS	11
3.2.2 FLOW SENSOR DIMENSIONS	11
3.2.3 INSTALLATION	12
4. ELECTRICAL CONNECTIONS	13
4.1 SAFETY INSTRUCTION	13
4.2 MUF 1200 WIRING DIAGRAM AND MODBUS REGISTER DETAILS	14
4.3 MUF 1200 MODBUS CONFIGURATION DETAILS OF FLOW METER TO BMS	14
4.4 CONNECTED TO POWER	15
4.5 LAYING ELECTRICAL CABLES CORRECTLY	16
4.6 EARTH CONNECTION	16
5. OPERATION	17
APPENDIX 1 : ERROR DIAGNOSES	35
APPENDIX 2: SERIAL INTERFACE USE AND COMMUNICATIONS PROTOCOL	36
APPENDIX 3 : Sound Velocity in Water	41



1. INTRODUCTION

1.1 PURPOSE OF THE MANUAL

Overview:

Welcome to the user manual for the Mial MUF 1200 – Inline Ultrasonic Flow meter. This comprehensive guide is designed to assist operators, maintenance personnel, and system integrators in understanding, installing, operating, and maintaining the Mial MUF 1200 – Inline Ultrasonic Flow meter effectively.

Objectives:

Clarification of Functionality: This manual aims to provide a clear understanding of the principles and functionality of the Mial MUF 1200 – Inline Ultrasonic Flow meter. Users will gain insights into its design, components, and how it precisely measures fluid flow.

Guidance for Installation:

Step-by-step instructions and considerations for proper installation are provided to ensure optimal performance. Safety precautions are emphasized to create a secure working environment.

Training and Familiarization:

Users will be guided through the features, controls, and indicators of the flow meter, facilitating efficient operation. This section aims to serve as a valuable training resource for users at various experience levels.

Maintenance and Troubleshooting Assistance:

Learn about routine maintenance procedures and effective troubleshooting techniques. This manual empowers users to address common issues and perform regular maintenance to enhance the longevity of the Mial MUF 1200 – Inline Ultrasonic Flow meter.

Intended Audience:

This manual is intended for operators, maintenance personnel, and system integrators involved in the installation, operation, and maintenance of the Mial MUF 1200 – Inline Ultrasonic Flow meter. It is suitable for both novice users seeking basic guidance and experienced professionals looking for specific details.

Important Notes:

Please read through the manual carefully, adhering to safety guidelines and following instructions precisely. If any uncertainties arise during the installation, operation, or maintenance processes, seek assistance from qualified personnel or our customer service / support team.

Reference to Other Documentation:

Refer to the accompanying technical specifications document for in-depth details about the Mial MUF 1200 – Inline Ultrasonic Flow meter. Additional resources can be found on our website.

Intended use



CAUTION!

Responsibility for the use of the measuring devices with regard to suitability, intended use and corrosion resistance of the used materials against the measured fluid lies solely with the operator.



INFORMATION!

The manufacturer is not liable for any damage resulting from improper use or use for other than the intended purpose



Certification




The manufacturer certifies successful testing of the product by applying the CE marking



The manufacturer certifies successful testing of the product by applying the ISO marking

1.2 OPERATING PRINCIPLE

The basic principle behind the operation of an inline ultrasonic flow meter revolves around the transmission and reception of ultrasonic signals through the flowing fluid. Typically, the flow meter consists of a pair of transducers placed opposite each other along the flow path. One transducer emits ultrasonic pulses, while the other receives them. As the fluid flows between the transducers, it carries the ultrasonic pulses with it. The transit time of these pulses between the transducers is measured. When the fluid flows with the direction of the pulses, they travel faster, and when it flows against the direction of the pulses, they slow down. By comparing the transit times of the pulses in both directions, the flow meter can accurately determine the velocity of the fluid. This velocity, combined with the cross-sectional area of the pipe, allows the flow rate to be calculated, providing valuable data for various industrial processes and applications





MUF 1200 specifications*

Operation and performance

Flow measurement

Ultrasonic differential transit-time Technology

Fluid types

Single medium, including a non-conductive medium and most clean liquids.

Fluid properties

Clean liquids in full (pressurized) pipes

Pipe sizes

50 MM – 300 MM

Pipe materials

metallic and non-metallic materials.

Flow Range

$\pm 0.09 \text{ ft/s} \sim \pm 16 \text{ ft/s}$ ($\pm 0.03 \text{ m/s} \sim \pm 5 \text{ m/s}$)

Flow accuracy

$\pm 1\%$ of the measured Value

Achievable with process calibration

Repeatability

$\pm 0.2\%$ of the measured value

Linearity

$\pm 1\%$

Measurement parameters

Flow Meter– Instantaneous flow, totalized flow

Certification

Calibration certification, CE, ISO

Electronics

Enclosures

ABS

Wall mounted enclosure

Enclosure IP rating

IP65

Memory

EEPROM

Power supply

24 VDC/2A

Use 2-amp SMPS when employing AC power

Ambient temperature

32°F to 140°F (0°C to 60°C)

Humidity

Up to 99% RH, non-condensing

Standard output

Analog output : 4 to 20 mA , 750 Ω maximum load

Pulse output– 0~9999Hz, OCT, (min. and max. frequency is adjustable)

Alarm Relay output

Network Connection

Modbus RTU RS 485

Data logging

8 GB removable memory card

Cable

10 Meter

Flow Tube

Operating Temperature range (Fluid)

5°F to 176°F (–15°C to 80°C)

Nominal Pressure

1.6 Mpa

Process connections

ANSI 150 Flanges

Materials

Flow Tube : Stainless steel 304

Flange : Carbon Steel

Optional: Stainless steel

IP rating

IP68

Meter installation orientation

Horizontal or Vertical

In a vertical installation, it is essential that the pipe be fully filled, with the flow direction oriented from bottom to top.

**Specifications are subject to change without prior notice.*



2. DEVICE DESCRIPTION

2.1 SCOPE OF DELIVERY



INFORMATION!

Do a check of the packing list to make sure that you have all the elements given in the order



INFORMATION!

Inspect the packaging carefully for damages or signs of rough handling. Report damage to the carrier and to the local office of the manufacturer.



INFORMATION!

The MUF 1200 transmitters and sensor bodies are components of a uniquely calibrated system and must be installed together as per the serial number. Mixing components from other systems will result in significant calibration errors. The transmitter serial number can be found on the sticker on the side of the electronics enclosure, and the sensor serial number is located on the sticker on the sensor body.

INFORMATION!




The field device will arrive in one standard cartons. The standard carton contains one small corrugated box containing Transmitter Unit. Also, the standard carton box contains Product documentation, Test Certificates, Mounting Accessories

INFORMATION!



Make sure to combine the sensor and the converter correctly, so they match by the devices serial number






2.2 NAME PLATES



INFORMATION!

Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate

EXAMPLE OF NAMEPLATE FOR THE TRANSMITTER



EXAMPLE OF NAMEPLATE FOR THE FLOW TUBE





3. INSTALLATION

3.1 SITE SELECTION


When selecting a site for a flow meter installation, prioritize accessibility for installation and maintenance. Consider environmental factors like temperature and humidity as per guidelines. Ensure the flow profile is stable and the pipe is in good condition. Safety and ease of access for personnel should also be taken into account to optimize meter performance and longevity.

3.1.1 BASIC RECOMMENDATIONS

In general guidelines, it's recommended to find a location where the pipe has the longest straight segment with a clear run. This ensures smooth laminar flow of the fluid through the meter, which is crucial for accurate measurement. A longer clear run of pipe minimizes disturbances and turbulence that could affect the meter's performance. This approach helps optimize the meter's accuracy and reliability by providing a stable flow profile for measurement.

3.1.2 FLOW DIRECTION

The Mial MUF 1200 Inline ultrasonic Flow meter should be installed ensuring the arrow indicated on the meter points in the direction of flow. When correctly installed, as illustrated, the arrowhead should align with the flow direction. The transmitter display will indicate positive values corresponding to the flow direction indicated by the arrow. If the fluid flows in the opposite direction to the arrow, the display will show negative readings reflecting the reverse flow direction.







3.1.3 INSTALLATION OF REMOTE MOUNT TRANSMITTER

Installing a remote mount transmitter involves placing the unit at a distance where the display is easily visible to the user. It should be positioned away from equipment that may generate electrical interference. The standard cable length from the flow tube to the transmitter becomes 10 meters and it can't be cut or extendable at the site. For the outdoor installation mandatory to provide a non-metallic FRP/GRP enclosure



3.1.4 STRAIGHT LENGTH REQUIREMENT

In order to ensure correct measuring, please pay attention to the requirements mentioned below. Having additional straight length beyond this minimum requirement offers additional advantages, such as enhanced measurement precision and reduced potential for turbulence or flow disturbances that could affect meter performance. Therefore, maximizing the straight length of the pipe where the flow meter is installed can contribute to optimizing the overall effectiveness and reliability of the measurement process.

SLOP & VERTICAL LINES







Install at the rising direction



Install at the rising direction





OPEN FEED OR DISCHARGE



INSTALL AT THE LOWEST POINT WHEN USED IN OPEN DRAIN PIPE



CONTROL VALVE



DON'T INSTALL IT AT THE EXIT OF THE VALVE, INSTALL IT AT THE ENTRANCE OF THE VALVE





POSITION OF PUMP



DON'T INSTALL IT AT THE ENTRANCE OF THE PUMP, INSTALL IT AT THE EXIT OF THE PUMP

DOWN GOING PIPELINE OVER 5 M /16 FT LENGTH



THE DOWNSTREAM OF FLOW METER WHEN THE DROP IS MORE THAN 5 M

3.2 MECHANICAL INSTALLATION




IMPORTANT NOTE!

MUF 1200 transmitters and sensor bodies are two parts of one uniquely calibrated system and must be installed together as per the serial Number . Mixing components from other systems will result in significant calibration errors.




3.2.1 STANDARD TRANSMITTER DIMENSIONS



3.2.2 FLOW SENSOR DIMENSIONS

ANSI CLASS 150 FLANGED SENSOR OVERALL DIMENSION




PIPE SIZE	L	D	A	N- Ø h	H
DN50	200	152	120.7	4-Ø19.1	255
DN65	220	178	139.7	4-Ø19.1	280
DN80	250	190	152.4	4-Ø19.1	285
DN100	250	229	190.5	8-Ø19.1	315
DN125	250	254	215.9	8-Ø22.4	340
DN150	300	280	241.3	8-Ø22.4	370
DN200	350	343	298.5	8-Ø22.4	430
DN250	450	406	362	12-Ø25.4	495
DN300	500	483	432	12-Ø25.4	558



3.2.3 INSTALLATION

Installation of this product should be carried out by qualified professionals, ensuring compliance with all relevant local, state, and federal building codes. Begin by thoroughly cleaning all flange surfaces to remove any old gasket material and adhesive residue. Inspect the flange surfaces for any warping, pitting, or imperfections that could affect the seal. Use new bolts, nuts, and hardened washers, and lubricate them to ensure even stress distribution during installation.

INSTALLATION DIAGRAM



i INFORMATION!

To ensure proper operation, MUF 1200 inline ultrasonic flow meters require a pressurized pipeline that is completely filled with clean water and free of air. The presence of entrained air in the line can interfere with the ultrasonic signals and disrupt the normal operation of the meters. It is essential to activate the air purge valves in the line to remove any entrained air from the system for the meters to function correctly.

i INFORMATION!

The head of the flow sensor should be installed at the 12 o'clock position on the pipe.

i INFORMATION!

The cable length from the flow sensor to the display is 10 meters and cannot be cut or extended on-site.



4 ELECTRICAL CONNECTIONS

4.1 SAFETY INSTRUCTIONS



DANGER!

Only when power is switched off, can we do all the work about electrical connections. Please pay all attention to the power supply on the name plate!



DANGER!

Observe the national regulations for electrical installations!



DANGER!

For devices used in hazardous areas, additional safety notes apply; please refer to the Ex documentation.



WARNING!

Observe without fail the local occupational health and safety regulations. Any work done on the electrical components of the measuring device may only be carried out by properly trained specialists.



INFORMATION!

Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate.



INFORMATION!

Connect the cable on connector with similar numeral marking




INFORMATION!

Ensure the meter operates correctly by supplying it with a dedicated 24 VDC input power source



4.2 MUF 1200 WIRING DIAGRAM AND MODBUS REGISTER DETAILS




4.3 MUF 1200 MODBUS CONFIGURATION DETAILS OF FLOW METER TO BMS

Function Code	Details	Register Address	Modbus Register	Register Type
03: Holding Register	Flow Rate	05	40005	Floating Point (32 bit)
	Flow Total	09	40009	Floating Point (32 bit)

Parity	: None
Word length	: 8
Stop Bit	: 1

*Note: If your BMS register address starts from '0', please decrement '1' value from every register.
Example: Flow rate register is 40005 then it should be configured as 40004.*



4.4 CONNECTED TO POWER




It is mandatory to provide an individual 24 VDC, SMPS (Switch Mode Power Supply) for energizing the flow meters. Additionally, it is essential to pull three-core wires (DC+, DC-, and ground) for the 24 VDC input power supply. As these are Inline Ultrasonic flow meters, a proper input power supply with an appropriate ground is crucial for their correct operations



DANGER!

The equipment must be grounded in accordance with regulations so as to protect the operator from electrical shock.

4.5 LAYING ELECTRICAL CABLES CORRECTLY



Keep the housing safe from dust and water

- i. Create a loop with the cable just before it reaches the housing.
- ii. Securely tighten the screw connection at the cable entry.
- iii. Always mount the housing with the cable entries facing downward.
- iv. Seal any unused cable entries with a plug.

4.6 EARTH CONNECTION



Proper earthing of the MUF 1200 Inline ultrasonic flow meter is critical for stable signal integrity, ensuring accurate flow measurements, and protecting against electrical hazards. Follow manufacturer guidelines closely for secure grounding to optimize performance and maintain safety standards throughout installation and operation.

<p>(1)</p> <p>Provide a quality Earth ground connection to the meter. From best to worst, grounding options include (stranded wire 14-18 AWG):</p>	<p>(2)</p> <p>Earth grounding rod driven into the ground</p>	<p>(3)</p> <p>Earth wire connected directly to the building electrical service panel ground.</p>
--	--	--



5. OPERATION

SYSTEM NORMAL IDENTIFICATION

If the letter "R" displays on the screen, it indicates system normal.

If the letter "D" is displayed, it indicates that system is adjusting the signal gain prior to the measurement. Also, it means system normal. Only when the adjustment takes too long without stopping, can system be identified as abnormal.

Letter "E" indicates no signal is being detected. Check the transducer wiring connections are correct, the transducers are installed firmly, etc.

For further information, please refer to "Error Diagnosis".

LOW FLOW CUTOFF VALUE

The data in M21 is Low Flow Cutoff Value. If the flow rate falls below the low flow cutoff value, the flow indication is driven to zero. This function can prevent the flow meter from displaying flow as "0" after a pump was shut down, but there is still liquid movement in the pipe, which will result in cumulative error. Generally, 0.03m/s is recommended to enter as the low flow cutoff point.

The low flow cutoff value has no relation to the measurement results once the velocity increases over the low flow cutoff value.

ZERO SETTINGS

Once zero flow occurs, a zero point may indicate on each measuring instrument, but the displayed measuring value is not equal to "0", this value indicates "Zero". To any measuring instrument, the smaller the "Zero" is, the better the quality is. Conversely, if the Zero is too big, that indicates the quality of the instrument is poor.

If the zero set point is not at true zero flow, a measurement difference may occur. The smaller the physical measurement capacity is, the larger the measurement difference from the zero point will exist. Only when zero point reduced to a definite degree, as compared with the physical measurement capacity, can the measuring difference from zero point be ignored.

For an Inline ultrasonic Flow meter, the measurement error from zero point cannot be ignored under low flow conditions. It is necessary to perform a static zero set calibration to improve low flow measurement accuracy.

CUTOFF ZERO

In Window M22- Cutoff- 1. Yes, window will show the —success! and back to M01 when you cut off the zero point successfully.

Performing Set Zero

In Window M22- Reset

SCALE FACTOR

Scale factor refers to the ratio between "actual value" and "reading value". For example, when the measurement is 2.00, and it is indicated as 1.98 on the instrument, the scale factor reading is 2/1.98. This means that the best scale factor constant is 1. However, it is difficult to keep the scale factor as "1" on the instrument especially in batch productions. The difference is called "consistency".

During operation, there still exists possible difference in pipe parameters, etc. The scale factor entered must be one that results from actual flow calibration. The scale factor can be input in Window M26.



SYSTEM LOCK

System lock is intended to prevent operation error due to tampering by unauthorized personnel. M54 is for system lock, unlock it by using the selected password only. If "lock" is displayed on the screen, then enter the correct password. Keep the password in mind or recorded in a safe place, otherwise the instrument cannot be used.

4 ~ 20mA ANALOG OUTPUT

With a current loop output exceeding an accuracy of 0.1%, the flow meter is programmable and configurable with outputs such as 4 ~ 20mA or 0 ~ 20mA selected in Menu 32. For details, please refer to Menu 32 in "Window Display Explanations".

In Window M32- Range- LowL, enter a 4mA flow value. Enter the 20mA flow value in Window M32-Range-UpperL. For example, if the flow range in a specific pipe is 0 ~ 1000m³/h, enter 0 in window M32-Range-LowL and 1000 in window M32-Range-UpperL.. If the flow ranges from -1000 ~ 0 ~ 2000m³/h, configure the 20 ~ 4 ~ 20mA output by selecting in Window M32 when flow direction is not an issue. Enter 1000 in Window M32 LowL and 2000 in Window M32 UpperL. When flow direction is an issue, module 0 ~ 4 ~ 20mA is available. When the flow direction displays as negative, the current output is in range of 0 ~ 4mA, whereas the 4 ~ 20mA is for the positive direction. The output module options are displayed in Window M32.

Calibrating and testing the current loop is performed in Window M32-Check. Complete the steps as follows: Use \uparrow and \downarrow to switch. "check 4mA", "check 8mA", "check 16mA", "check 20mA" readings, connect an ammeter to test the current loop output and calculate the difference. Calibrate the 4-20mA is in M62.

FREQUENCY OUTPUT

The flow meter is provided with a frequency output transmitter function. The high or low frequency output displayed indicates the high or low flow rate reading. The user can reset the frequency output as well as flow rate as the user's actual requirements.

For example: if a pipe flow range is 0 ~ 5000m³/h, the relative frequency output required is 100 ~ 1000Hz, and the configuration is as follows:


In Window M33-Range-LowerL (lower limit frequency output flow value), input 0;

In Window M33-Range -UpperL (upper limit frequency output flow value), input 5000;

In Window M33-Mode-F range (frequency range), input 100、1000;

In Window M33-Mode-Option, select —a. Flow Rate;

Typical OCT Output wiring diagram as shown



TOTALIZER PULSE OUTPUT

Each time the flow meter reaches a unit flow, it may generate a totalizer pulse output to a remote counter. The totalizer pulse output can be transmitted through OCT or a relay. Therefore, it is necessary to configure OCT and the relay accordingly. (Please refer to Window M33 and M34). For example, if it is necessary to transmit the positive totalizer pulse through a relay, and each pulse represents a flow of 10m³, the configuration is as follows:

In Window M41-Unit, select the totalizer flow unit "m³";



In Window M41-MULT, select the scale factor "e. x10";
In Window M34-Option, select "g. POS Total";



ATTENTION

Make sure to select an appropriate totalizer pulse. If the totalizer pulse is too big, the output cycle will be too long; if the totalizer is too small, the relay will operate too faster, you may shorten the life of the relay, as well as skip some pulses. The totalizer is recommended to transmit within the range of 1 ~ 3 pulse per second.

ALARM PROGRAMMING

The on-off output alarm is generated through OCT or transmission to an external circuit by opening or closing a relay. The on-off output signal is activated under the following conditions:

- (1) Signal not detected;
- (2) Poor signal detected;
- (3) The flow meter is not ready for normal measurement;
- (4) The flow is in the reverse direction (back flow).
- (5) The analog outputs exceed span by 120%.
- (6) The frequency output exceeds span by 120%.
- (7) The flow rate exceeds the ranges configured (Configure the flow ranges using the software alarm system. There are two software alarms: Alarm#1 and Alarm #2.

Example 1: When flow rate exceeds 300 ~ 1000 m3/h, in order to program the relay output alarm, Complete the steps as follows:

- (1) In Menu 35, Alarm1 LowL 300;
- (2) In Menu 35, Alarm1 Upper 1000;
- (3) In Menu 34, Relay Setting-Option- d Alarm1

4-20mA ANALOG OUTPUT CALIBRATION



Each flow meter is meticulously calibrated before leaving the factory. Recalibration is generally unnecessary unless the value displayed in Window M32 during current loop calibration does not match the actual output current value.

The hardware detect window must be activated prior to calibration the Analog Output. The procedure is as follows: Menu 62 is for 4-20mA calibration, if you need enter the password . With no effect to next power on, this window will close automatically as soon as the power is turned off. Use —↑| and —↓| to switch. Calibrate the current loop 4mA output. Use an ammeter to measure the output current of current loop and adjust the displayed numbers at the same time. Watch the ammeter until it reads 4.00. Stop at this point, the 4mA has been calibrated. Use —↑| and —↓| to switch. Calibrate the current loop 20mA output. The method is the same as 4mA calibration. The results are automatically saved inEEPROM and won't lose when power off.



SD CARD OPERATION

SPECIFICATIONS

Data collection interval: any interval settings from 1 to 3600 seconds are OK according to the requirement.

Data content: date and time, flow rate, flow velocity, total flow, positive totalizer, negative totalizer.

Data storage format:

a=2017-11-16,16:21:12

b=+2.652471E+00 m3/h

c=+9.380460E-02 m/s

d=+3.520580E+02 m3

e=+3.520580E+02 m3

f=+0.000000E+00 m3

g=+0.000000E+00 GJ/h

h=+0.000000E+00 GJ

i=+0.000000E+00 GJ

j=+0.000000E+00`C

k=+0.000000E+00`CFile

system format: FAT16.

File type: plain text file (.TXT).

File number: maximum 512pcs.

It can save 120 bytes of data each time. If it is set to save once in per 5 seconds, the capacity of storing file in 24 hours is $120 \times 3600 / 5 \times 24 = 2073600 \text{ byte} \approx 2.1 \text{ Mbyte}$, therefore, 1Gbyte SD card can store for days: $1024 / 2.1 = 487.6 \approx 487$ days. When the capacity of the SD card is full, the new data will override the earliest files automatically.

INSTALL OR REMOVE THE SD CARD WHILE THE METER IS POWERED ON



ATTENTION

Do not remove or insert the SD card from the reader while the flow meter is powered on, as this can result in data loss or corruption. It is mandatory to turn off the flow meter before removing or inserting the SD card. Save and store the data from the SD card in a separate location on the PC before processing it. Processing data directly from the SD card file location on the PC could also lead to data loss or corruption.

ESN We provide the flow meter with a unique electronic serial number to identify each flow meter for the convenience of the manufacturer and customers. The ESN, instrument types and versions are able to view in Window M50.



M00
Flow Total
Display Net Totalizer.
Display Positive totalizer.
Display Negative totalizer.

M00	Flow total		*R
NET	POS	NEG	
203.1			E + 0 m ³

M01
Flow Rate
Display the Flow Rate and Flow Total

Display the Flow Velocity.
Flow Total and Flow Velocity switch every 6 seconds,
with the ENTER key used to halt the transition

M00	Flow total		*R
NET	POS	NEG	
203.1			E + 0 m ³

M00	Flow total		*R
NET	POS	NEG	
203.1			E + 0 m ³

M01	Flow Rate		*R
0.582			m/s
71.2			m ³ / h

M04
Status
Display the Signal strength, the Upstream signal strength and Downstream signal strength.

Signal quality Q is indicated by 00 ~ 99. Therefore, 00 indicates the poorest signal while 99 indicates the best signal.

Display the measured fluid sound velocity. Normally this value should be approximately equal to the entered value in Window M12. If the difference is too large, it probably results from an incorrect value entered in Window M12.

Display the ratio between the actual measured transmit time and the calculated transmit time according to customer's requirement. Normally the ratio should be 100 ±3%

Display the measured ultrasonic average time (unit: us) and delta time of the upstream and downstream (unit: ns) time. The velocity calculation in the flow meter is based on the two readings. The delta time is the best indication that the instrument is running steadily.

M04	Status		*R
Signal	Sound	Time	
UP	DN	Q	
91.0	91.0	99	

M04	Status		*R
Signal	Sound	Time	
Vel.	1499.9	m/s	
Ratio	100.0%		



M10
Pipe settings
Enter the pipe size;
Important Note:
This menu is exclusively designated for use by the manufacturer during wet calibration at the factory. Users are emphatically cautioned against altering the values without prior permission from the manufacturer.

M04	Status		*R
Signal	Sound	Time	
Total	177.6	us	
Delta	76.7	us	

M10	Pipe Settings		*R
Size	Method	Comp	
Option	5.DN200		

M10	Pipe Settings		*R
Size	Method	Comp	
Option	0.Channel 1		

M10	Pipe Settings		*R
Size	Method	Comp	
CH 1	0.000		

M11
Lining
Only the manufacturer should operate this menu. Users are strongly advised against entering or modifying any values within this menu.

M11	Lining		*R
Size	M.		
Thk.	3.0	mm	

M11	Lining		*R
Size	M.		
Option	0.No Liner		
Other	2400.0	m/s	



M12

Medium

Select the temperature of water. Temperature should be 0-60 deg. C. Press —Enter| to confirm. Note: Room temperature is 25 deg C

M12	Medium	*R
Type	VIS	
Option	14.Other	
Other	1499.2	m/s

M20

Damping

The damping factor ranges from 1 ~ 999 seconds. 1 indicates no damping; 999 indicates the maximum damping.
The damping function will stabilize the flow display. Usually a damping factor of 3 to 10 is recommended in applications.

M12	Medium	*R
Type	VIS	
VIS	1.0038	cSt

M21

Low Vel. Cut off

Low Flow Cut off is used to make the system display as "0" value at lower and smaller flows to avoid any invalid totalizing. For example, if the cutoff value is set as 0.03, system will take all the measured flow velocity values from - 0.03 to + 0.03 as "0". Generally, 0.03 is recommended in most applications.

M 20	Damping	*R
value	1	

M22

Zero Settings

When fluid is in the static state, the displayed value is called "Zero Point". When "Zero Point" is not at zero in the flow meter, the difference is going to be added into the actual flow values and measurement differences will occur in the flow meter. Set zero must be carried out after the transducers are installed and the flow inside the pipe is in the absolute static state (no liquid movement in the pipe). Thus, the "Zero Point" resulting from different pipe mounting locations and parameters can be eliminated. The measuring accuracy at low flow is enhanced by doing this and flow offset is eliminated. Select "YES"; reset "Zero Point" which was set by the user.

This method is not commonly used. It is only suitable for experienced operators to set zero under conditions when it is not preferable to use other methods. Enter the value manually to add to the measured value to obtain the actual value. For example:

Actual measured value = 240 m³/H

Value Deviation = 10 m³/H

Flow meter Display = 250 m³/H

Normally, set the value as "0".

Use — ↑ | and — ↓ | to switch

M21	Low Vel. Cutoff	*R
Value	0.03	m/s

M22	Zero Setting	*R
Cutoff	Reset	Offset
Option	0.No	

M22	Zero Setting	*R
Cutoff	Reset	Offset
Option	0.No	



M23
Totalizer
Select the totalizer type
0. POS Positive Totalizer
1. NEG Negative Totalizer
2. NET
Select "ON"/"OFF" to switch the totalizer.
Totalizer - Reset
Select the flow totalizer value you want Reset
0. POS Positive Totalizer
1. NEG Negative Totalizer
2. NET
3. All

M22 Zero Setting *R		
Cutoff	Reset	Offset
Value	0.0	

M23 Totalizer *R		
Switch	Reset	
Flow	0.POS	0.ON

M23 Totalizer *R		
Switch	Reset	
Flow	0.POS	

M25
Power Down Correction Switch
With the function of power down automation correction switch, the flow lost in an offline session can be estimated and automatically adjusted. The estimate is based on the average value, which is obtained from flow rate before going offline and flow measured after going online the next time, multiplied times the time period that the meter was offline. Select "ON" to use this function, select "OFF" to cancel this function.

M25 Power off COMP *R		
Switch	Reset	
Option	1.OFF	

M26
K Factor
The K factor is used to modify the measurement results. The user can enter a numerical value (other than "1") according to the actual calibration results.

Important Note:
This menu is exclusively designated for use by the manufacturer during wet calibration at the factory. Users are emphatically cautioned against altering the values without prior permission from the manufacturer.

M26 K Factor *R		
Value	1.039	

M27 Correction *R		
KArray	Delay	TPC
Option	1.OFF	
Value	*****	



M27

Correction

K-Array

Sectional Correction

ON: Open the Sectional Correction Function;

OFF: Close the Sectional Correction Function

Delay correction

Engineer menu, suggest customer use the factory setting.

TPC

Transducers power control

Engineer menu, suggest customer use the factory setting.

0. Auto

1. Low

2. High

Important Note:

This menu is exclusively designated for use by the manufacturer during wet calibration at the factory. Users are emphatically cautioned against altering the values without prior permission from the manufacturer.

M28

SQA

Statistic Analysis

M30

RS232/RS485

Serial Port Setting

. 2400 None

. 4800 None

. 9600 None

. 19200 None

. 38400 None

. 56000 None

You can setting the order as following : a. 1-0: 3-2

b. 0-1:2-3

c. 3-2:1-0

d. 2-3:0-1

M27	Correction	*R
KArray	Delay	TPC
Value	0.6	us

M27	Correction	*R
KArray	Delay	TPC
Option	1.Auto	

M28	SQA	*R
Set	Reset	
Option	0.ON	
Value	0.000	

M28	SQA	*R
Set	Reset	
Option	0.Auto	
Value	0.000	

M30	RS232/RS485	*R
Set	Order	
Option	c.9600	None
ID	55	

M30	RS232/RS485	*R
Set	Order	
Option	a.1-0 : 3-2	



M31
AI Setting
Display analog input AI1 analog value.
Display analog input AI2 analog value.

M31	AI Settings		*R
A1	A12	Value	
LowerL	0.0		
UpperL	1000.0		

M31	AI Settings		*R
A1	A12	Value	
A11	0.0		
A12	0.0		

M32
CL Setting
Current Loop Mode Options
Select the CL Range value
Set the CL output value according to the flow value at 4mA or 0mA.
Set the CL output value according to the flow value at 20mA.
4-20mA check options
a. Check 4mA
b. Check 8mA
c. Check 12mA
d. Check 20mA

M32	CL Settings		*R
Mode	Range	Check	
Option	a. 4-20mA		

M32	CL Settings		*R
Mode	Range	Check	
LowerL	0.0	m³/h	
UpperL	430.0	m³/h	

M32	CL Settings		*R
Mode	Range	Check	
Option	0.Check	0mA	

M33	OCT Settings		*R
Mode	Range	Check	
Option	0.Flow Rate		
FRange	0-1000	Hz	



M33
OCT Setting
The following signal options are available:
a. Flow Rate
b. POS Total
c. NEG Total
d. NET Total
h. Rationing
i. Uart CTRL
Select the OCT Range value.

OCT check options
a. Check 500
b. Check 1000
c. Check 3000
d. Check 5000

M33 OCT Settings *R		
Mode	Range	Check
LowerL	0.0	m ³ / h
UpperL	430.0	m ³ / h

M33 OCT Settings *R		
Mode	Range	Check
Option	0.Check	500

M34
Relay Setting
The following signal options are available: a. No Signal
b. *E
c. Reverse d. Alarm1 e. Alarm2 f. Ration
g. POS Total h. NEG Total i. NET Total j. Not Using

M34 Relay Settings *R		
Option	0.Not Using	

M35
Alarm Setting
Enter the Lower alarm value, any of the measured flow, which is lower than the low value, will activate the alarm in the OCT hardware or relay output signal. Enter the Upper alarm value, any of the measured flow, which is higher than the high value, will activate the alarm in the OCT hardware or relay output signal.

M35 Alarm Settings *R		
Alarm1	Alarm2	
LowerL	0.0	m ³ / h
UpperL	0-1000	m ³ / h

M35 Alarm Settings *R		
Alarm1	Alarm2	
LowerL	0.0	m ³ / h
UpperL	0-1000	m ³ / h

M37
Micro SD
Following is the options for the record.
a. No Energy
b. All
Input the data collection time interval in this menu. Time is in seconds. The interval can be selected in the range of 1 ~ 3600 seconds.

M37 Micro SD *R		
Option	a.No Energy	
Cycle	600s	



M40
Toggle Unit
Select the measurement unit as follows:
a. Metric
b. British

M40	Toggle Unit	*R
Option	a .Metric	

M41
Flow Unit
The following flow rate units are available:
0. Cubic Meters (m³)
1. Liters (l)
3. Imperial Gallons (Imp gal)
4. Million Gallons (mg)
5. Cubic Feet (cf)
6. USA Barrels (US bbl)
7. Imperial Barrels (Imp bbl)
8. Oil Barrels (Oil bbl)

The following time units are available:
/Day /Hour
/Min /Sec
Factory default is Cubic Meters/hour.
The Multipliers programmable for flow consumption are

a. x 0.001 (E-3)	b. x0.01 (E-2)
c. x 0.01 (E-1)	d. x1 (E+0)
e. x 10 (E+1)	f. x100 (E+2)
g. x1000 (E+3)	h. x10000 (E+4)

M41	Flow Unit	*R
Unit	MULT.	
Rate	m ³ / h	
Rate	m ³	

M41	Flow Unit	*R
Unit	MULT.	
Option	d. *1	

M50
Serial Number
Display electronic serial number (S/N) of the instrument. This S/N is the only one assigned to each flow meter ready to leave the factory. The factory uses it for files setup and for management by the user. SVN is the software version

M50	Serial Number	*R
S/N	F200###6	
SVN	V1 . 18	

M51
Time and Date
Date and time modifications are made in this menu.

M51	Time/Date	*R
Time	18:31:07	
Date	20##-01-30	

M52
Key Tone
Use this menu to —ON/ —OFF the key tone.

M52	Key Ton	*R
Option	0 . ON	



M54
System Lock
Once the system is locked, any modifications to the system are prohibited but the parameters remain readable. The only way to unlock the flow meter is by entering the manufacturer-provided password, which consists of six numbers. Please contact the representative or manufacturer as soon as possible if the password is lost.

M54	System Lock	*R
Option	c. Not Using	

M55
System Reset
Select 1. Reset to make the instrument back to factory.

M55	System Reset	*R
Option	c. None	
Menu	M01	

M60
Date Totalizer
The following options are available:
0. Day
1. Month
2. Year
In this window, it is possible to review the historical flow data net totalizer for any day for the last 31 days, any month for last 12 months and any year for last 6 years.

M60	Date Totalizer	*R
Day	Mon	Year
Value	01 - 05	E + 0
	0.0	m ³

M60	Date Totalizer	*R
Day	Mon	Year
Value	00 - 01	E + 0
	0.0	m ³

M60	Date Totalizer	*R
Day	Mon	Year
Value	2000	E - 3
	0.0	m ³

M61
Running Time
With this function, it is possible to view the total Working days since the flow meter left the factory.

M61	Running Time	*R
Value	67	



M62
CL Adjust
This menu is for the 4-20mA calibration; enter the password to adjust.

M62	CL Adjust	*R
4 mA	Enter to go	
20 mA	Enter to go	

M64
RTD Adjust
This menu is for the AI calibration; enter the password to adjust.

M64	AI Adjust	*R
AI1	AI2	
4 mA	Enter to go	
20 mA	Enter to go	

M64	AI Adjust	*R
AI1	AI2	
4 mA	Enter to go	
20 mA	Enter to go	



APPENDIX -1 Error Diagnoses

The Inline ultrasonic flow meter has advanced self-diagnostics functions and displays any errors in the upper right corner of the LCD via definite codes in a date/time order. Some errors can be detected during normal operation. Undetectable errors caused by unskilled operation, incorrect settings and unsuitable measurement conditions can be displayed accordingly during work. This function helps the user detect the errors and find causes quickly; thus, problems can be solved in a timely manner according to the solutions listed in the following table. If a problem still exists, please contact the factory or the factory's local representative for assistance.

Table 1. Error Codes and Solutions (during operation)

Codes	The upper right corner of the screen	Causes	Solutions
*R	System Normal	* System normal.	
*E	Signal Not Detected	* Flow meter installed improperly. * Scaling inside the pipe. * New pipe liner.	* Check the initial parameter settings. * Re-install the flow meter in a different location with less pipe scaling. * Wait until liners solidified and saturated.
*D	Adjusting Gain	* Adjusting gain for normal measurement.	



APPENDIX -2 – Serial Interface Use and Communications Protocol

Overview

The flow meter features an excellent communication protocol and can be connected via RS-485 Modbus. When the serial port communications method is directly used to implement a monitoring network system, the address identification code of the flow meter is used as a network address code. Expanded command set with [W] is used as communication protocol. RS-485 (cable length 0 ~ 1000m) can be directly used for data transmission links for a short distance. Current loop can be used in medium or long-distance transmission.

When the flow meter is used in a network environment, various operations can be performed by a host device, except for programming of the address identification code, which needs to be done via the flow meter keyboard.

The command answer mode is used in data transmission, i.e. the host device issues commands and the flow meter answers correspondingly.

A data character string is used to express basic commands and a carriage return (ENTER) is used to express the end of a command. The characteristic is that the string of data is flexible. The order applies to both RS232 and RS485. Frequently used commands are as follows: Communications commands

Command	Description	Data format
RFR(cr)(lf)	Return instantaneous flow	±d.dddddE±dd(cr) Note 1
RVV(cr)(lf)	Return instantaneous velocity	±d.dddddE±dd(cr)
RT+(cr)(lf)	Return positive accumulative flow	±ddddddd.dE±d(cr) Note 2
RT-(cr)(lf)	Return negative accumulative flow	±ddddddd.d±d(cr)
RTN(cr)(lf)	Return net accumulative flow	±ddddddd.d±d(cr)
RTH(cr)(lf)	Return net accumulative energy(hot)	±ddddddd.d±d(cr)
RT-(cr)(lf)	Return net accumulative energy(cold)	±ddddddd.d±d(cr)
RER(cr)(lf)	Return instantaneous energy value	±d.dddddE±dd(cr)
RA1(cr)(lf)	Return analog input value of AI1 (Temperature, Pressure, etc.)	±d.dddddE±dd(cr)
RA2(cr)(lf)	Return analog input value of AI2 (Temperature, Pressure, etc.)	±d.dddddE±dd(cr)
RID(cr)(lf)	Return Net address of the instrument	dddd(cr) 5 bits in length
RSS(cr)(lf)	Return signal intensity	UP:dd.d, DN:dd.d, Q=dd(cr)
REC(cr)(lf)	Return current error code	*R/*D/*E Note 3
RRS(cr)(lf)	Return Relay Status	ON/OFF(cr)
RDT(cr)(lf)	Current date and time	yy-mm-dd, hh:mm:ss(cr)
SFQddd.d(cr)(lf)	OCT setting	ddd.d(cr) Successful setting will back to —OKI
SCLdd.d(cr)(lf)	Current setting	dd.d(cr) Successful setting will back to —OKI
SRS(cr)(lf)	Start quantitative control	OK(cr) Successful setting will back to —OKI
P	Prefix of return command with check	Note 5
W	Networking command prefix of numeric string address	Note 6



NOTE

1. (cr)expresses carriage return. Its ASCII value is 0DH. (lf) expresses line feed. Its ASCII value is0AH.
2. " d" expresses 0-9 number. 0 value is expressed as +0.000000E+00.
3. "d" expresses 0-9 numbers. There is no decimal point in integral part before "E".
4. dddddddd means the serial number of the instrument, t means the model of the instrument.
5. The character P can be added before every basic command. It means that the transferred datahas CRC verification. The method of verification is to add all of the data back to the data, which is cumulative and binary, and its low 8-bit binary data is taken.

E.g. The return information of the RT(cr)(lf) is :+1234567E+0m3(cr)(lf), (the relative binary system data is 2BH, 31H, 32H, 33H, 34H, 35H, 36H, 37H, 45H, 2BH, 30H, 6DH, 33H, 20H, 0DH, 0AH) The sum of all of its return data is =2BH+31H+32H+33H+34H+35H+ 36H+37H+45H+2BH+30H+6DH+33H+20H=2F7, The low 8-bit data of its binary is F7. Therefore, the data of the order PRT (cr) (lf) is called + 1234567E + 0m3!F7 (cr) (lf), "!"For delimiters, the preceding is the character of the summation, followed by a check code of 1 byte.

6. Usage of prefix W: W+ numeric string address code +basic command. Value range of the numeric string is 0 ~ 255, except 13 (0DH carriage return), 10 (0AH line feed). If the instantaneous velocity of No. 123 flow meter is to be accessed, the command W123DV (cr)(lf) can be issued. The corresponding binary code is 57H, 31H, 32H, 33H, 44H, 56H, 0DH, 0AH,only
7. W and P commands can be used in combination, for example, W123PRT +, which means that the instrument that reads the network address is the cumulative value of the instrument with123, and its return data has eight accumulations and checksums."s" expresses ON or OFF or UD. For example,"TR:ON, RL:ON" expresses that the OCT and relay are in an actuated status;"TR:UD, RL:UD" expresses that the OCT and relay are not actuated.

MODBUS-I Communication Protocol

This MODBUS-I Protocol uses RTU transmission mode. The Verification Code uses CRC-16-IBM (polynomial is $X^{16}+X^{15}+X^2+1$, shield character is 0xA001) which is gained by the cyclic redundancy algorithm method.

MODBUS-I RTU mode uses hexadecimals to transmit data.

MODBUS-I Protocol Function Code and Format

The flow meter protocol supports the following two-function codes of the MODBUS:

Function Code	Performance data
0x03	Read register
0x06	Write single register

MODBUS Protocol function code 0x03 usage

The host sends out the read register information frame format:

Slave Address	Operation Function Code	FirstAddress Register	Register Number	Verify Code
1 byte	1 byte	2 bytes	2 bytes	2 bytes
0x01 ~ 0xF7	0x03	0x0000 ~ 0xFFFF	0x0000 ~ 0x7D	CRC (Verify)



The slave returns the data frame format:

Slave Address	Read Operation Function Code	Number of Data Bytes	Data Bytes	Verify Code
1 byte	1 byte	1 byte	N*x2 byte	2 bytes
0x01 ~ 0xF7	0x03	2xN*	N*x2 (Data)	CRC (Verify)

N* = Data register number

MODBUS Protocol function code 0x06 usage

The host sends a command to write a single register information frame format (function code 0x06):

Slave Address	Operation Function Code	RegisterAddress	Register Data	Verify Code
1 byte	1 byte	2 bytes	2 bytes	2 bytes
0x01 ~ 0xF7	0x06	0x0000 ~ 0xFFFF	0x0000 ~ 0xFFFF	CRC (Verify)

The slave returns the data frame format (function code 0x06):

Slave Address	Operation Function Code	RegisterAddress	Register Data	Verify Code
1 byte	1 byte	2 bytes	2 bytes	2 bytes
0x01 ~ 0xF7	0x06	0x0000 ~ 0xFFFF	0x0000 ~ 0xFFFF	CRC (Verify)

The CRC Verify Code adopts CRC-16-IBM (polynomial is $X^{16}+X^{15}+X^2+1$, shield character is 0xA001) which is gained by the cyclic redundancy algorithm method. Low byte of the verify code is at the beginning while the high byte is at the end.

For example, to read the address 1 (0x01) in the RTU mode, if the instantaneous flow rate uses hour as a unit (m³/h) , namely reads 40005 and 40006 registers data, the read command is as follows:

0x01 0x03 0x00 0x04 0x00 0x02 0x85 0Xca
Flow meter Address Function Code First Address Register Register Numbers CRC Verify Code

Flow meter returned data is (assuming the current flow=1.234567m³/h)

0x01 0x03 0x04 0x06 0x51 0x3F 0x9E 0x3B 0x32
Flow meter Address Function Code Data Bytes Data (1.2345678) CRC Verify Code

The four bytes 3F 9E 06 51 is in the IEEE754 format single precision floating point form of 1.2345678.



Pay attention to the data storage order of the above example. Using C language to explain the data, pointers can be used directly to input the required data in the corresponding variable address, the low byte will be put at the beginning, such as the above example 1.2345678 m/s, 3F 9E 06 51 data stored in order as 51 06 9E 3F.

For example, it converts the address 1 (0x01) to 2 (0x02) under the RTU mode, so to write the data of Flow meter 44100 register as 0x02, the write command is as follows:

0x0 0x06 0x10 0x03 0x00 0x02 0xFC 0xCB
Flow meter Address Function Code Register Address Register Number CRC Verify Code

Flow meter returned data is:

0x01 0x06 0x10 0x03 0x00 0x02 0xFC 0xCB
Flow meter Address Function Code Register Address Register Number CRC Verify Code

Error Check

The flow meter only returns one error code 0x02 which means data first address in error.

For example, to read address 1 (0x01) of the flow meter 40002 register data in the RTU mode, the flow meter considers it to be invalid data, and sends the following command:

0x01 0x03 0x00 0x01 0x00 0x01 0xD5 0xCA
Flow meter Address Function Code Register Address Register Number CRC Verify Code

Flow meter returned error code is:

0x01 0x83 0x02 0xC0 0xF1
Flow meter Address Error Code Error Extended Code CRC Verify Code

MODBUS Register Address List

The flow meter MODBUS Register has a read register and a write single register.

a) Read Register Address List (use 0x03 function code to read)

PDU Address	Register	Read	Write	Type	No. registers*
\$0000	40001	Flow/s - low word	32 bits real	2	
\$0001	40002	Flow/s - low word			
\$0002	40003	Flow/m - low word	32 bits real	2	
\$0003	40004	Flow/m - high word			
\$0004	40005	Flow/h - low word	32 bits real	2	
\$0005	40006	Flow/h - high word			
\$0006	40007	Velocity – low word	32 bits real	2	
\$0007	40008	Velocity – high word			
\$0008	40009	Positive total – low word	32 bits int.	2	
\$0009	40010	Positive total – high word			



\$000A	40011	Positive total – exponent	16 bits int	1	
\$000B	40012	Negative total – low word	32 bits int	32 bits int	
\$000C	40013	Negative total – high word			
\$000D	40014	Negative total – exponent	16 bits int.	1	
\$000E	40015	Net total – low word	32 bits int.	2	
\$000F	40016	Net total – high word			
\$0010	40017	Net total – exponent	16 bits int.	1	
\$0011	40018	Energy flow – low word	32 bits int	2	
\$0012	40019	Energy flow – high word			
\$0013	40020	Energy total(hot) –low word	32 bits real	2	
\$0014	40021	Energy total(hot) –high word			
\$0015	40022	Energy total(hot) – exponent	16 bits int.	1	
\$0016	40023	Energy total(cold) –high word	32 bits real	2	
\$0017	40024	Energy total(cold) – exponent			
\$0018	40025	Energy total(cold) – exponent	16 bits int	1	
\$0019	40026	Up signal int – low word	32 bits real	2	0 ~ 99.9
\$001A	40027	Up signal int – high word			
\$001B	40028	Down signal int – low word	32 bits real	2	0 ~ 99.9
\$001C	40029	Down signal int – high word			
\$001D	40030	Quality	16 bits int.	1	0 ~ 99
\$001E	40031	Error code – char 1	String	1	Refer to "Error Analysis" for detailed codes meanings.
\$003B	40060	Flow velocity unit –char 1,2	String	2	Only m/s right now
\$003C	40061	Flow velocity unit –char 3,4			
\$003D	40062	Flow rate unit –char 1,2	String	2	Note 1
\$003E	40063	Flow rate unit –char 3,4			
\$003F	40064	Flow total unit – char 1,2			
\$0040	40065	Energy rate unit – char 1,2	String	2	Note 2
\$0041	40066	Energy rate unit – char 3,4			
\$0042	40067	Energy total unit – char 1,2	String	1	
\$0043	40068	Instrument address –low word	32 bits real	2	
\$0044	40069	Instrument address –high word			
\$0045	40070	Serial number – char 1,2	String	4	
\$0046	40071	Serial number – char 3,4			
\$0047	40072	Serial number – char 5,6	String	4	
\$0048	40073	Serial number – char 7,8			
\$0049	40074	Analog Input AI1 Value- low word			Returned temperature value with RTD option
\$004a	40075	Analog Input AI1 Value- high word			
\$004b	40076	Analog Input AI2 Value- low word	32 bits real	2	
\$004c	40077	Analog Input AI2 Value- high word			
\$004d	40078	4-20mA Value- low word	32 bits real	2	Unit: mA
\$004e	40079	4-20mA Value- high word			



APPENDIX :3 Sound Velocity in Water (1 atm) at different temperatures

t (°C)	v(m/s)	t (°C)	v(m/s)	t (°C)	v(m/s)
0	1402.3	34	1517.7	68	1554.3
1	1407.3	35	1519.7	69	1554.5
2	1412.2	36	1521.7	70	1554.7
3	1416.9	37	1523.5	71	1554.9
4	1421.6	38	1525.3	72	1555.0
5	1426.1	39	1527.1	73	1555.0
6	1430.5	40	1528.8	74	1555.1
7	1434.8	41	1530.4	75	1555.1
8	1439.1	42	1532.0	76	1555.0
9	1443.2	43	1533.5	77	1554.9
10	1447.2	44	1534.9	78	1554.8
11	1451.1	45	1536.3	79	1554.6
12	1454.9	46	1537.7	80	1554.4
13	1458.7	47	1538.9	81	1554.2
14	1462.3	48	1540.2	82	1553.9
15	1465.8	49	1541.3	83	1553.6
16	1469.3	50	1542.5	84	1553.2
17	1472.7	51	1543.5	85	1552.8
18	1476.0	52	1544.6	86	1552.4
19	1479.1	53	1545.5	87	1552.0
20	1482.3	54	1546.4	88	1551.5
21	1485.3	55	1547.3	89	1551.0
22	1488.2	56	1548.1	90	1550.4
23	1491.1	57	1548.9	91	1549.8
24	1493.9	58	1549.6	92	1549.2
25	1496.6	59	1550.3	93	1548.5
26	1499.2	60	1550.9	94	1547.5
27	1501.8	61	1551.5	95	1547.1
28	1504.3	62	1552.0	96	1546.3
29	1506.7	63	1552.5	97	1545.6
30	1509.0	64	1553.0	98	1544.7
31	1511.3	65	1553.4	99	1543.9
32	1513.5	66	1553.7		
33	1515.7	67	1554.0		



MIAL[®]
INSTRUMENTS PVT.LTD.
Measuring & Beyond

USA OFFICE ADDRESS

MIAL INSTRUMENTS PVT. LTD.
Downtown Republic Center
325 N. St.Paul Street, Suite 3100
Dallas 75201, Texas, USA

FACTORY ADDRESS

MIAL INSTRUMENTS PVT. LTD.
856/ 6 GIDC
Makarpura, Vadodara 390010, Gujarat, India
+91-9913449547/9913449548

Email : info@mialinstruments.com
www.mialinstruments.com



**MIAL
INSTRUMENTS**
Measuring & Beyond

856/6, GIDC MAKARPURA, VADODARA - 390010
Phone : +91-9913449547 / +91-9913449548
E-MAIL : info@mialinstruments.com
WWW : www.mialinstruments.com